



10. Replace the Extension Clamp to

shotgun

complete the re-assembly of the

11. (Optional) Install UTG tactical rails (MNT-P501, 502, 503, 505) on the

forearm for flashlight, laser or other accessory applications.

6. Pull the original Fore-end out from

the Fore-end Tube Assembly.

Pull the front end of the Barrel

Assembly out from the Receiver.

forward to remove the Barrel

5. Remove the Fore-end Tube Nut

by turning it counterclockwise

with a screwdriver or a special

tool.