

180MM X 98MM



SUPER SLIM 2-PIECE DROP-IN CAR LENGTH RAIL SYSTEM

for Car Length AR15 with Barrel Nut & Round Front Cap

Item No.: MTU001SS

- Proudly Designed and Manufactured in USA
- Fits Carbine Length AR15 with Delta Ring and Round Front Cap
- Lightweight, Slim Tubular Profile for Most Positive Handling
- Top Rail Extending to Upper Receiver for Continuous Mounting Platform
- Includes 2 Short Side Rails with 2 Slots Each and 2 Long Side Rails with 4 Slots Each for Accessory Configuration at 3, 6 and 9 O'clock Positions
- Precision Machined from Aircraft Aluminum with Black Anodizing
- Simple and Friendly Installation, No Gunsmithing Required

MUM03081331



SUPER SLIM 2-PIECE DROP-IN CAR LENGTH RAIL SYSTEM

for Car Length AR15 with Barrel Nut & Round Front Cap

Item No.: MTU001SS

Made in USA

AR15 SUPER SLIM 2-PIECE DROP-IN CAR LENGTH RAIL SYSTEM INSTALLATION GUIDE

MTU001SS

Caution: Make sure firearm is not loaded. Remove magazine and examine chamber. Use safe handling procedures at all times.



1 Use a handguard removal tool to pull down the Delta Ring and remove the handguard.



2 Separate the Top Cover (with 1 rail) from the Bottom Cover (with no rail). Use the flush cut side of the Top Cover to enclose and cover the Front Handguard Cap. Align the Top Cover properly with the receiver top using the top rail as an index.



3 Use the handguard removal tool to pull down the Delta Ring. Slowly drop the Tapered Rear End of the Top Cover into the Barrel Nut by aligning the 2 inner Spinal Cords against the Central Groove Area in the Barrel Nut. Once fit into position, release the Delta Ring to cover the Tapered Rear End of the Top Cover snugly. If the Top Rail of the Top Cover is not centered with the receiver top, minor adjustment on the Barrel Nut is required. Remove the handguard rail to adjust the barrel nut position. Repeat step 2 and 3 until the optimal indexing is achieved.



4 Identify the Tapered Rear End of the Bottom Cover. Install it onto the rifle by aligning the 2 inner Spinal Cords against the Central Groove Area in the Barrel Nut, press downward the Bottom Cover to push down the Delta Ring, and then release forward toward the barrel to snugly enclose and cover the Front Handguard Cap.



5 Secure the Top and the Bottom Covers with the 2.5mm Allen wrench and 4x M4 screws. Then, use the 2mm Allen wrench to install 2x M4 set screws at the Delta Ring end of the Bottom Cover to further secure the rail system. For the 4 user-configurable side rails included in the product, use the 2.5mm Allen wrench and the M3.5 locking screws for installation to the handguard.

Note: Do not over tighten or use power tool for all fastener installation. If desired apply small amount of locking compound to the threads prior to tightening.