



Website: www.leapers.com
Telephone: 734-542-1500
E-mail: office@leapers.com



BIG BORE

FULL STABILITY

BIPOD

USER MANUAL

For Model: TL-BPFS01

BIPOD INSTALLATION


 Ensure firearm is unloaded before installation and follow all basic rules of firearms safety.



1. Position the bipod so that the tilt tension adjustment lever is facing away from the muzzle.



2. Loosen the side locking plate nut by turning it counterclockwise. Loosen it enough for the mounting interface to seat evenly onto your firearm's MIL-STD-1913 Picatinny rail and with its squared recoil stop fitting into the rail slot.



3. Retighten the side locking plate nut by turning it clockwise until snug or to 50in-lb using a torque wrench equipped with a 5/8" socket.

5 POSITION BIDIRECTIONAL FOLDING



1. Push down the posi-lock push button until you feel its locking lugs disengage, allowing you to rotate the bipod leg to another position.



2. The locking lugs automatically lock at each of the five folding positions.

LEG EXTENSION HEIGHT ADJUSTMENT



1. To unlock the bipod leg extension for height adjustment, turn its locking thumb wheel counterclockwise until it stops.



2. Pull down the foot pad to increase the length of the leg extension. Note that the leg extension is under spring tension as it is designed to automatically retract. The leg extension is keyed and once at the desired length is secured in place by turning back the locking thumb wheel clockwise until it stops.



3. To automatically retract the leg extension, unlock the locking thumb wheel first and then press the release tab above it down.



1. Turning the tilt tension adjustment lever to the right decreases tilt tension.



2. Turning the tilt tension adjustment lever to the left increases tilt tension.



1. Rotating the panning tension adjustment lever completely forward decreases panning tension.



2. Rotating the panning tension adjustment lever completely rearward increases panning tension.

The Best Never Rest Warranty - Lifetime

Leapers, Inc. warrants that all UTG & UTG PRO products conform to published specifications and are free from defects in material and workmanship. We will repair or replace defective products for the duration of the product's life span. Our dedicated and professional in-house customer service team will go above and beyond to make things right and provide the best in-class customer service experience you expect to receive.

Our warranty does not extend to products damaged from misuse, accidental damage, negligence, natural disasters/accidents, or unauthorized repair or alteration.

For warranty service, please submit your inquiry by visiting our customer service page on our website at www.leapers.com or give us a call at 734-542-1500. A Return Authorization Number (RMA) must be assigned before returning any products for warranty service.