

TACTICAL QUAD RAILS

MNT-HG228

Caution: Make sure firearm is not loaded. Remove magazine and examine chamber. Use safe handling procedures at all times.













Remove all the receiver filler Press the Spacer into the screws and the Front Barrel Band.

TOP COVER AIL RAIL

BOTTOM COVER

front end of the Top Cover. Place the Top Cover on the gun by aligning the Tail Rail on the receiver and its front end on the barrel. Make adjustment carefully until the Top Cover sits stably.

Fit the Bottom Cover onto the front stock. Make sure the two connecting walls of the Bottom Cover fit into the two mating channels of the Top Cover. Align the screw holes on the Top and Bottom Covers. . If necessary, put some of provided rubber sheets in the front side of the Bottom Cover to improve the fitting effect.



Tighten the front four screws with the provided Allen wrench to secure the Top and Bottom Covers. Make sure the Top and Bottom Covers are both horizontal. Do not over tighten the screws.

four slotted screws on the under side of the Rubber Rail Tail Rail for secure fit and Guard to a desired rail slot best zero retention capabil- on a rail. Extend the Rubber ity. Quad Rail system is Rail Guard to horizontally designed to allow for rear situate the Locking Nub into sight use after installation.

Use a screwdriver to tighten Align the Locking Nub in the the rail slot. Push the whole piece to click into the rail for a tight fit.



