



416M MODEL 4/15

MID LENGTH QUAD RAILS

MNT-T416MA

- Fits Mid Length Model 4, 15 and 16 Rifles with Delta Ring and Triangular Front Cap
- Four Mil-spec Picatinny Rails Each with 18 Slots for Versatile Accessory Applications
- Precision Machined from Aircraft Alluminum with Black Anodizing
- Simple and Friendly Installation, No Gunsmith or Tool Required
- Solid Locking Features for Most Secure Fit
- Ultimate Tactical Solution to Enhance Accuracy Under Toughest Environments

MUM006011001



MNT-T416MA

416M MODEL 4/15 MID LENGTH QUAD RAILS

MODEL 4/15 MID LENGTH QUAD RAILS INSTALLATION GUIDE

MNT-T416MA

Caution: Make sure firearm is not loaded.
Remove magazine and examine chamber.
Use safe handling procedures at all times.



1. Use a handguard removal tool to pull down Delta Ring and remove the handguards.



2. Separate the metal quad rails into the Top Cover (3 rails) and the Bottom Cover (1 rail). Install the Top Cover onto the barrel by aligning the inner two spinal cords against the central groove area in the barrel nut, and push for a tight fit.



3. Press downward the Top Cover to push down the Delta Ring, and then release toward the Handguard Front Cap. Make sure the 4 integral alignment tabs at the front of the mount are properly sandwiched the front cap (middle 2 small alignment tabs are inside of the front cap-see the green area, and the other 2 large side tabs are outside of the front cap-see the red area).



4. Press downward the Bottom Cover to push down the Delta Ring, and then release toward the Handguard Front Cap. Make sure the 3 integral alignment tabs at the front of the mount are properly positioned to firmly sandwich the front cap (2 small alignment side tabs are inside of the front cap-see the green area, and the middle large tab is outside of the front cap-see the red area).



5. Tighten all 4 screws using the provided Allen wrench to secure the Top and the Bottom Covers. The Quad-Rail System is ready for most versatile accessory applications.



CENTRAL GROOVE AREA



FRONT HANDGUARD CAP



BOTTOM COVER

ALIGNMENT ASSEMBLY TABS

TOP COVER

CORRECT INSTALLATION

