

## MODEL 4 EXTENSION TUBE AMBI SLING MOUNT

with QD Loop





Remove the two screws from the adapter with the provided Allen wrench



**Optional:** Apply 1-2 pieces of Synthetic Tape provided with the mount for optimal fit with mil-spec receiver tube (OD: 1.146").



Open clamp and close around receiver extension tube (making sure the Anti-rotational Tab is inserted into the Recess on the tear drop ring in the stock assembly).



Reinstall the two screws and tighten with Allen wrench securely (20 in - lbf).



Detach and re-attach the QD Loop by pushing the center button in completely to retract the inner ball bearings for release. The QD Loop can be attached from either end of the adapter for ambidextrous use.

## TL-SWR02



Website: www.leapers.com Telephone: 734-542-1500

Make sure safety is on and gun is unloaded!

E-mail: office@leapers.com